0F3SR580C150000 FTR-S030

TRIUMPH 675 SLIPPER CLUTCH KIT

MOUNTING INSTRUCTION

The Drum/Hub group is supplied pre-assembled. In case of need, as to check the 901 VT 018 ramps wear, please see hereinafter the specific procedure to disassemble the (1)Screw Drum/Hub aroup Place the Drum/Hub group on the drive shaft. WARNING: between the original basket and the hub (18) you must keep the washer of the original clutch, otherwise there could be generated wrong 901 RD 007 (2)function and/or damage to the clutch parts. Notched washer Replace the original clutch plates, keeping in the original sequence. Please remind to replace last OEM steel plate (that one with teeth different from others) with another steel plate equal to others OEM steel plates. At the end of the operation the 0F3SR580C150004 (3) total height of the stack must be 42.8mm +-0.3mm. Bearing rest WARNING: if in the original plates kit there are two rings (one of them is 0F3SR580B150013 (4)conical), placed in between sinterized plates keep them apart and do NOT Clutch nut use them in the STM clutch 0F3SR540D220017 (5)Check that the drum stopper lock screw (14) do not stick out from the surface of the Notched washer drum stopper (15), where the spring stopper hub (6) will be placed. Verify that the secondary spring support (13) is correctly placed in its seat in the 0F3SR580B150007 drum (16). Place the secondary spring (12) in the drum (16) with a small amount of (6) Spring stopper hub grease Check that the primary spring support (10) is correctly placed in its seat in the Pressure plate (11). Place the pressure plate (11) in its seats on the drum (16). Place the Evoluzione primary spring (9) on the pressure plate (11). 003 MG 007 (7) Ball bearing Pre-assemble the spring stopper group: keep the spring pusher plate (8) with the groove for the bearing facing up as shown in the drawing, place the ball bearings (7) and then place the spring stopper hub (6). Insert the spring stopper group into the pressure plate (11) so that the 9 wings of 0F3CR620E07A008 (8) the spring pusher plate (8) overlap the 9 tips of the spring (9). Spring pusher plate Insert the notched washer(5) with the convex part facing up and then the nut (4) in the spring stopper hub (6). Tighten the nut (4) onto the drive shaft and lock it with a dynamometric wrench to the torque suggested by the manufacturer. To lock the pressure plate (11) we 0S1121 (9) suggest to use the specific tool (UTL-0030, not included). Evoluzione primary Pre-assemble the bearing rest group: mount the clutch pushrod piece and the sprina bearing of the original clutch into the bearing rest (3). Place the entire bearing rest into the specific holes in the pressure plate (11) taking care of placing it correctly in these holes and fix it with the six screws (1) and with the notched washers (2). 0F3SR540B140015 Primary spring support Once the mounting operations are completed, operate the clutch lever more (10)than once to check that pressure plate correctly activate the clutch opening and closing, then mount the clutch guard. DRUM/HUB UN-INSTALL PROCEDURE ATTENTION: DO NOT perform this operation before removing the clutch from 0F3SR580B150003 (11)the bike. Remove the drum stopper lock screw (14), rotate the drum stopper hub Pressure plate (15) clockwise by 60° and then remove it. The drum (16), the hub (18) and the steel balls (17) can now be disassembled. TO RE-ASSEMBLE THE GROUP: place the 6 steel balls (17) at the bottom of the 0S2085 grooves of the hub (18) using a small amount of grease, then position the drum Secondary spring (14) onto the hub (18) in an at-rest position. Position the drum stopper hub (15) on (12)the hub (18), aligning its three wings with the three housings on the hub (18), then rotate it until the holes of the two parts are aligned, and finally replace completely 0F3SR540B140016 the screw (15). Check that the drum stopper (15) is correctly locked on the hub (18) and that the drum stopper lock screw (14) do not stick out from the Secondary spring (13)surface where the spring stopper hub (6) will be placed. support 0F3SR300J070086 (14)Drum stopper lock screw 0F3SR580B15B009 (15) Drum stopper GENERAL SAFETY REGULATIONS 0F3SR580C1502A3 (16) IN THIS SHEET ARE REPORTED THE DIRECTIONS TO PERFORM CORRECTLY THE CLUTCH Drum ASSEMBLY OPERTIONS - STM RESERVES THE RIGHT, WITHOUT NOTICE, TO INTRODUCE ANY TECHNICAL CHANGE WHENEVER DEEMED IT TO BE NECESSARY TO IMPROVE FUNCTION AND QUALITY OF THE PRODUCTS ASSEMBLY OPERATIONS MUST BE PERFORMED BY A SKILLED TECHNICIAN AND MUST BE SCRUPULOUSLY OBSERVED SCRUPULOUSLY OBSERVED. • BEFORE MOUNTING THE CLUTCH MAKE A COMPLETE INSPECTION OF THE MOTORBIKE COMPONENTS, IN ORDER TO VERIFY THE POSSIBLE PRESENCE OF FAULTS OR ANOMALIES ON THE VEHICLE. • STM ITALY SRL PRODUCTS ARE EXCLUSIVELY INTENDED FOR COMPETITION, NOT SUITABLE ON MOTORBYKES ON PUBLIC ROADS. • MAKE SURE THAT THERE ARE NO MISSING/DAMAGED PARTS IN THE CLUTCH KIT. • SOME PARTS OF THE CLUTCH AND ITS COMPONENTS CAN HAVE SHARP SURFACE: <u>HANDLE</u> WITH CARE 001 MG 025 (17)0 Steel balls D WITH CARE. - SOME COMPONENTS OF THE CLUTCH, BECAUSE OF THEIR SMALL DIMENSIONS CAN BE SWALLOWED: KEEP AWAY FROM CHILDREN. 0F3SR580C1501A3 (18)Hub